
Screw regulator Assembly to wall

## **Regulator Assembly**

To adjust high and low pressure regulator: Pull out the red adjusting knob, turn the knob clockwise to increase pressure, counterclockwise to decrease the pressure. When the needle is at the right pressure push the knob in to lock.

\*\*\*Be sure to use clamps on all tubing connections and pinch the "ear" together to avoid leaks



\*\*\* The Pumps have to be connected to syrup, to shut off, or they will keep pumping... You can disable the pump, by sliding the "horseshoe" Clip toward you, and pull the CO2 fitting out, Stright down, and it has a "auto-shut" off built into it.

machine has developed a sufficient ice bank to reduce temperature of dispensed drink. This can take up to 4 hours.