


Screw regulator
Assembly to wall

Regulator Assembly

To adjust high and low pressure regulator:
Pull out the red adjusting knob, turn the knob clockwise to increase pressure, counterclockwise to decrease the pressure. When the needle is at the right pressure push the knob in to lock.

***Be sure to use clamps on all tubing connections and pinch the "ear" together to avoid leaks



On multiple pump units a Bright Yellow "Tee" will replace a Bright Yellow "EL".

*** The Pumps have to be connected to syrup, to shut off, or they will keep pumping... You can disable the pump, by sliding the "horseshoe" Clip toward you, and pull the CO2 fitting out, Straight down, and it has a "auto-shut" off built into it.

Note: Carbonation Levels will be low until the machine has developed a sufficient ice bank to reduce temperature of dispensed drink. This can take up to 4 hours.